

STORM SYSTEM®


Storm Medium Cabinet Concrete is an accessory for STORM SYSTEM® MEDIUM fixtures. It is designed to make it possible to integrate the STORM SYSTEM® MEDIUM in concrete ceilings.

The Storm Medium Concrete Cabinet is available in three heights, and if your installation depth is limited you can choose either height B or C. The minimum height will depend on your chosen product/light engine.



HEIGHT A







STORM MEDIUM CONCRETE CABINET

DATA

Collection	STORM SYSTEM®
Product	Storm Medium Concrete Cabinet
Article no.	1A01.0082.xx – height A
	1A01.0083.xx – height B
	1A01.0084.xx – height C

Refer to the installation depth table on the following page to determine the appropriate height option of the Cabinet Universal (in regards to the product and additional light engine)

SPECIFICATIONS

Weight	33,5 g – 37,5 g
Material	Polycarbonate
IP protection grade	IP44
Wiring capacity	0,5-2,5mm2 AWG 20-14
Approvals	CE
Cabling	Installation cable 90°C
Fixture finish	For xx-codes review STORM SYSTEM® – COLOUR CODES

CABLE CONNECTION

Included: Rubber grommet

Optional: • Cable gland M16 (not included • Conduit Ø16 available in local stores)



NOTE

With Low Voltage light engines, LED Driver must be placed remotely. Storm Medium Concrete Cabinet cannot house the LED driver.

OPTIONAL ACCESORY

Storm Medium Recess Plug - custom accesory

If applied, the Storm Medium Recess Plug replaces the Storm S Base. Before installation, remove the spring from the Storm S Base, and add it to the Storm Medium Recess plug, then follow the assembly instructions.

The custom recess plug requires concrete form oil in order to optimize release of the form, this proces must be clarified on site. It is crucial for the final result, that the assembly instructions have been followed.

It is recommended that a test cast is made, to ensure that all parties agree upon the final result.






STORM MEDIUM CABINET CONCRETE

HOOK 1A01.0109.xx(yy) MOON 1A01.0108.32(yy) SUN	HOOK 1A01.0109.xx(yy) MOON	HOOK 1A01.0109.xx(yy) MOON 1A01.0108.32(yy) SUN 1A01.0113.32(yy) PLUTO	HOOK 1A01.0109.xx(yy) MOON 1A01.0108.32(yy) SUN 1A01.0113.32(yy) PLUTO 1A01.0130.62(yy) VENUS 1A01.0131.62(yy) OUTPUT 1A01.0500.xx	HOOK 1A01.0109.xx(yy) MOON 1A01.0108.32(yy) SUN 1A01.0113.32(yy) PLUTO 1A01.0130.62(yy) VENUS 1A01.0131.62(yy) OUTPUT
	1A01.0113.32(yy)	1A01.0113.32(yy) PLUTO 1A01.0130.62(yy) VENUS	1A01.0113.32(yy) PLUTO 1A01.0130.62(yy) VENUS 1A01.0131.62(yy) OUTPUT 1A01.0500.xx	1A01.0113.32(yy) PLUTO 1A01.0130.62(yy) VENUS 1A01.0131.62(yy) OUTPUT 1A01.0500.xx





IMPORTANT INFORMATION

Installation and mounting must be performed by skilled personnel only, and instructions must be followed.


CLEANING AND MAINTENANCE: Use a soft moist cloth for cleaning. No further maintenance is required.

WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

COMPONENTS

- Storm Medium Cabinet Concrete
 - Cabinet (either height A, B or C)
 - 2 rubber grommets
 - 1 screw
 - Storm Medium Back-Mounted Ring
 - Storm Medium S Base






STORM MEDIUM CABINET CONCRETE

ASSEMBLY INSTRUCTION PAGE 1 OF 3


STEP 1

Mark out on the underlay, where you want your installations to be.




STEP 2

Place the Storm S Base over the mark, and mark out the position for the screws. Then fasten the screws to the underlay




STEP 3

Place the Storm S Base over the screws, rotate slightly and fasten the screws.



STEP 4

Place the reinforcement mesh (if using this) over the Storm S Base.



STEP 5

- 1. Fasten the cable conduit connection to the cabinets outlets
- 2. Click the Cabinet onto the Storm Medium Back-Mounted Ring. MAKE SURE IT SNAPS!







2

IMPORTANT INFORMATION

Installation and mounting must be performed by skilled personnel only, and instructions must be followed.

CLEANING AND MAINTENANCE: Use a soft moist cloth for cleaning. No further maintenance is required.

WARRANTY:


If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

STORM MEDIUM CABINET CONCRETE

ASSEMBLY INSTRUCTION PAGE 2 OF 3


STEP 6

Mount the Storm Medium Cabinet Concrete onto the Storm S Base




STEP 7

Make sure that the two componants are completely flush with the underlay.




STEP 8

Anchor the Storm Medium Cabinet Concrete to the reinforcement mesh.



STEP 9

Make sure that the concrete completely surrounds the Storm installation ring.



STEP 10

When the concrete is dry pull down the underlay.







IMPORTANT INFORMATION

Installation and mounting must be performed by skilled personnel only, and instructions must be followed.

CLEANING AND MAINTENANCE: Use a soft moist cloth for cleaning. No further maintenance is required.

WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

STORM MEDIUM CABINET CONCRETE

ASSEMBLY INSTRUCTION PAGE 3 OF 3

STEP 11


Feed the supply cable through the conduit and out through the Storm Medium Cabinet Concrete.



STEP 12


INSTALLATION OF A LIGHT FIXTURE

Due to accessibility after installation the cable must be stripped to a length of 25cm, and then connected to the terminal which accompanies the light fixture



STEP 13

Connect the light engine to the terminal, then mount the terminal back in place and secure the screw.



NOTE

Guide the cables along the edge, then secure the terminal to the top with the accompanying screw.

