

#### X-curve

Enrich your table with the X-curve pendant by ONE A. The sleek X-curve pendant consists of an anodized base with a beautiful hand-wrapped leather cord detail - honoring ONE A's design philosophy.

The pendant is ideal for dining- and meeting tables as it is dimmable and therefore enables you to create the desired atmosphere. Honeycombs in the lamp-heads prevent glaring.





The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal

For more information, please contact info@onea.dk

## X-CURVE

## DATA

Collection	ONE A
Product	X-curve
Article no.	1A11.4071.XX66.36ZZ (X-C6)
	1A11.4072.XX66.36ZZ (X-C12)

## **SPECIFICATIONS**

Material	Aluminium and leather
Labelling	CE

## ELECTRICAL SPECIFICATIONS

Voltage	230V
Dim	Yes – compatible with leading and trailing edge phacecut dimmers
Insulation class	Class I 🚇
IP protection grade	IP20
Light Source	LED included – 1AL.20.DW 🔉
Beam	36° Lens
Energy Class	This product contains energy class G light sources

## DIMMER COMPATIBILITY

			BU Dimmer																						
A				В			С			D			E			F			G			Н			
Dinner			elder ele SBD315F			VADSB VD200			NIKO (310-016)		BUSCH (6523U)		OPUS (T39.01)		OPUS (39.07)		OPUS (T39.08)			OPUS (T46.03)					
	<	Result	Pnax	Pnin	Result	Pnax	Pnin	Result	Pmas	Pnin	Result	Pmas	P <sub>min</sub>	Result	Pnas	P <sub>min</sub>	Result	Pmax	Pmin	Result	Pmax	Pmin	Result	Pmax	Pmin
	200V	1	8.664	1.792	1	8.493	0.811		9.176	1.835	1	8.29	Cut off	1	9.133	Cut off	1	9.133	Cut off	~	9.09	Cut off	1	8.45	2.006
1AL, 20. XX	240V	1	8.664	2.176	1	8.536	1.195	slightly flash at	9.603	4. 225	1	9.346	Cut off	1	9.517	Cut off	1	9.688	Cut off	1	9.56	Cut off	1	8.45	2.432
	264V	1	8.706	2.39	1	8.664	1.408	the low	9.517	6, 103	1	9.517	2.048	1	10.24	Cut off	1	9.944	Cut off	1	9.816	Cut off	1	8.536	2.817

### XX-COLOUR CODES

92 Black Pearl	93 Elephant Grey
97 Gold	98 Silver

### ZZ-COLOUR CODES

92 Black Leather 95 Dark Brown Leather 94 Tan Leather 96 Green Leather

## STANDARDS:


EN 60598-1 EN 60598-2-1 EN 55015

## NOTE

3m cord included Metal wire suspension included









# X-CURVE

SUSPENSION

X-C6 Wires: 3 Effect: 48W Weight: 5,2 kg





X-C12

Wires: 3 Effect: 96W Weight: 11 kg



### IMPORTANT INFORMATION

Installation and mounting must be performed by skilled personnel only, and instructions must be followed.

Always shut the power circuit off before starting work.

In some countries electoral installation work may only be carried out by an authorized electrical contractor. Please contact your local electricity authority for advice.

If the external flexible cable is damaged, it MUST be replaced by a special cable exclusively available from the manufacture.

The light sources contained within this fixtures MUST only be replaced by the manufacture or a similarly qualified person.

### CLEANING AND MAINTENANCE:

Use a soft moist cloth for cleaning. No further maintenance is required.


### WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

## X-CURVE wire suspension

## ASSEMBLY USING STORM OUTPUT

Suspension wire can be mounted in Storm Output, for further information refer to Storm Output's technical information. Feed the accompanying steel wire throught the small hole in Storm Output, then fasten the screw






## ASSEMBLY INSTRUCTION

## STEP 1


STEP 3


Mount the wire suspension to the ceiling with a screw.



STEP 2 Mount the wire lock in the wire suspension.

Guide the wire through the wire lock







#### IMPORTANT INFORMATION

Installation and mounting must be performed by skilled personnel only, and instructions must be followed.

Always shut the power circuit off before starting work.

In some countries electoral installation work may only be carried out by an authorized electrical contractor. Please contact your local electricity authority for advice.

If the external flexible cable is damaged, it MUST be replaced by a special cable exclusively available from the manufacture.

The light sources contained within this fixtures MUST only be replaced by the manufacture or a similarly qualified person.

#### CLEANING AND MAINTENANCE:

Use a soft moist cloth for cleaning. No further maintenance is required.

#### WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

## X-CURVE wire suspension

STEP 4


Then pull the wire out through the slot



## STEP 5

Connect wire to power outlet. Make sure to obtain cable strain relief, check power outlet for instructions.

- N Neutral (blue)
- Ground (Green/Yellow)
- L Line (Brown)





#### IMPORTANT INFORMATION

Installation and mounting must be performed by skilled personnel only, and instructions must be followed.

Always shut the power circuit off before starting work.

In some countries electoral installation work may only be carried out by an authorized electrical contractor. Please contact your local electricity authority for advice.

If the external flexible cable is damaged, it MUST be replaced by a special cable exclusively available from the manufacture.

The light sources contained within this fixtures MUST only be replaced by the manufacture or a similarly qualified person.

## CLEANING AND MAINTENANCE:

Use a soft moist cloth for cleaning. No further maintenance is required.


### WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

## X-CURVE


## LIGHT SOURCE REPLACEMENT

STEP 1






STEP 2 Pull back the spring.



## STEP 3

Disconnect the light source and replace with the new light source.



### STEP 4

Gently release the spring. Then mount the front tube by slightly rotating the tube into place.

